


Configuration Chart

Button	Appliance	Via	Function	Code
1				
2				
3				
4				
5				
6				
7				
8				

Quick-Start Guide to setting up Scanning Remote.

1

Make sure Scanning Remote battery is charged or is powered from wall adapter. Press Function to make sure the unit is awake.



2

Fill out the Configuration Chart (overleaf) with your required button functions.


3

Pair each button with its receiver by pressing Pair on the receiver and then BOTH Pair/Learn and the relevant touch button on Scanning Remote.



4

Once the 'P' appears on the display, press any further buttons you may wish to form part of the same pairing group. You can add these until the P is extinguished.



5

Now set the function of each button by pressing Function to select and Pair/Learn to change.